


Parts Information:

Hot Air Gun 1800W 3-Speed 50/420/650°C **Model No: HS100**



Item	Part No.	Description
1	HS100.01	Heat Proof Cover
2	HS100.02	Tube
3	HS100.03	Mica Sheet
4	HS100.04	Heating Element
5	HS100.05	Screw
6	HS100.06	Fan Cover
7	HS100.07	Fan
8	HS100.08	Screw
9	HS100.09	Motor Support
10	HS100.10	Motor (Internal 2000W)
11	HS100.11	Housing, Left Side
12	HS100.12	Plate
13	HS100.13	Bar

Item	Part No.	Description
14	HS100.14	Back Cover
15	HS100.15	Inductor
16	HS100.16	Switch Push Button
17	HS100.17	Rubber Cover
18	HS100.18	Circuit Board
19	HS100.19	Power Cable
20	HS100.20	Cable Sleeve
21	HS100.21	Casing Screw ST4x14
22	HS100.22	Cable Plate
23	HS100.23	Housing, Right Side
24	HS100.24	Casing Screw ST3x14
25	HS100.25	Casing Screw ST3x18

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk

