




3 TONNE TROLLEY JACK

60977 - TJ3HD/BR SPARE PARTS DRAWING / LISTING



Key No.	Part No.	Stock No.	Description
1	YTJ3HD/BR-01	61687	Frame unit
2	YTJ3HD/BR-02	61704	Rear wheel
3	YTJ3HD/BR-03	61706	Nut
4	YTJ3HD/BR-04	61711	Front wheel
5	YTJ3HD/BR-05	61716	Flat washer
6	YTJ3HD/BR-06	61796	Spring washer
7	YTJ3HD/BR-07	61799	Power unit assembly
8	YTJ3HD/BR-08	61800	Screw
9	YTJ3HD/BR-09	61805	Circlip
10	YTJ3HD/BR-10	61806	Lift arm
11	YTJ3HD/BR-11	61818	Lift arm axle
12	YTJ3HD/BR-12	61822	Saddle
13	YTJ3HD/BR-13	61824	Lubricating nipple
14	YTJ3HD/BR-14	61826	Connecting rod bolt
15	YTJ3HD/BR-15	61828	Circlip
16	YTJ3HD/BR-16	61830	Connecting rod
17	YTJ3HD/BR-17	61839	Cotter pin
18	YTJ3HD/BR-18	61840	Spring
19	YTJ3HD/BR-19	61841	Circlip
20	YTJ3HD/BR-20	61843	Washer

Key No.	Part No.	Stock No.	Description
21	YTJ3HD/BR-21	61844	Nut
22	YTJ3HD/BR-22	61845	Short handle yoke bolt
23	YTJ3HD/BR-23	61846	Washer
24	YTJ3HD/BR-24	61847	Torsion spring
25	YTJ3HD/BR-25	61848	Oil drain valve
26	YTJ3HD/BR-26	61857	Shaft
27	YTJ3HD/BR-27	61858	Rear shaft
28	YTJ3HD/BR-28	61859	Cotter pin
29	YTJ3HD/BR-29	61860	Washer
30	YTJ3HD/BR-30	61861	Gear
31	YTJ3HD/BR-31	61862	Washer
32	YTJ3HD/BR-32	61864	Nut
33	YTJ3HD/BR-33	61865	Handle yoke bolt
34	YTJ3HD/BR-34	61866	Nut
35	YTJ3HD/BR-35	61869	Lower handle
36	YTJ3HD/BR-36	61874	Handle cover
37	YTJ3HD/BR-37	61884	Screw
38	YTJ3HD/BR-38	61887	Handle yoke
41	YTJ3HD/BR-41	61903	Upper handle
**	YTJ3HD/BR-42	61954	Rubber saddle