

BANDSAW STAND



Original Instructions
Version 1
March 2025


84718 (Suitable for use with Bandsaw 84714 and other similar machines)

Stock No.	84718
Part No.	ABS10
Stand height when assembled	413mm

Unpacking and Checking

Carefully remove the product from the packaging and examine it for any signs of damage that may have occurred during shipment. If any part is damaged or missing, do not attempt to use the product. Please contact the Draper Helpline; contact details can be found at the bottom of this leaflet.

What's in the Box?



- (1) 4 X Leg upright (2) 2 x Short side support
- bracket
 (3) 2 X Long side support
 bracket
- (4) Support bracket fixings 8 X M6 X 12mm Screws
 - 8 X 6.5mm Washers
- 8 X M6 Nuts
- (5) Stand leg fixings
 - 8 X M8 X 12mm Hex bolts 8 X 8.5mm Washers

Assembly

Important: The stand should be used if not securing the bandsaw directly to a workbench. Predrilled holes are provided in the bandsaw's base plate for this purpose.



Fig. 1




Fig. 2

- 1. Secure the stand legs (1) to the bandsaw with fixings (5) see Fig.1.
- 2. Assemble the support brackets (2) and (3) to the legs (1) with fixings (4) see Fig. 2.



WARNING! Examine the supporting surface carefully when the bandsaw is mounted to ensure that no movement will occur during use. If any tipping or walking is noted secure the workbench or supporting surface before operating the bandsaw.

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 Internet: drapertools.com Email: sales@drapertools.com