

DRAPER

EN

Original Instructions
Version 1 - July 2025

AUTOMOTIVE CIRCUIT TESTER

Stock No. **99752** Part No. **1169C**



Instructions for Use

1. Connect the crocodile clip (earth connection) to a suitable earth.
2. Place the tip of the contact probe on the part to be tested.
3. If current is present the light will glow.



WARNING!

- For testing DC circuits on vehicles within the voltage range of 6 – 24V **only**.
- **NOT** suitable for testing mains supply AC circuits.

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333
General Enquiries: +44 (0) 23 8026 6355 Website: drapertools.com Email: sales@drapertools.com

Draper Tools Limited, Hursley Road, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF, UK Draper Tools Europe B.V., Oude Graaf 8, 6002 NL, Weert, Netherlands

© Published by Draper Tools Limited